## DALI LED Power Supply CW-WW

### Datasheet

**Control Gear** 

DALI LED Power Supply (DT8) for independent control of light level and colour temperature of tuneable white luminaires

> constant voltage: Art.Nr. 89453849-CWW-24V (24V, 25W)

### constant current: Art.Nr. 89453849-CWW-350 (15W, 350mA) Art.Nr. 89453849-CWW-500 (20W, 500mA) Art.Nr. 89453849-CWW-700 (20W, 700mA) Art.Nr. 89453849-CWW-800 (20W, 800mA) Art.Nr. 89453849-CWW-1000 (20W, 1000mA) Art.Nr. 89453849-CWW-1050 (20W, 1050mA)



## DALI LED Power Supply CW-WW Control Gear

### Overview

- DALI LED Power Supply for the control of tuneable white luminaires
- types for constant voltage and constant current LED-modules available
- Operating Mode DT8: one DALIaddress for the independent control of light level and colour temperature (DALI DT8, Colour Type Tc)
- Operating Mode Balance&Dim: control by 2 DALI-addresses, one for adjusting the light level and one for adjusting the channel balance (e.g. colour temperature)
- Operating Mode Dim2Warm: one DALI-address for simultaneous adjustment of light level and colour temperature

- SwitchDim2: 2 switch-inputs offer control of level and colour without DALI
- dimming range 0.1%-100%
- adjustable PWM-frequency (122Hz/244Hz/488Hz/976Hz from FW version 5 on changed PWM frequencies: 122Hz / 250Hz / 500Hz / 1kHz)
- supply voltage 230V AC
- CV-Type: output 24V PWM (max. 1A)
- CC-Type: output currents of up to 1050mA
- configuration via PC-software DALI-Cockpit and DALI USB-interface
- overtemperature shutdown, integrated short circuit protection
- user-friendly factory default settings

### Specification, Characteristics

#### constant voltage (CV)

type	DALI 25W LED Power Supply CW-WW CV 24V
article number	89453849-CWW-24V
electrical data	
supply voltage	220-240V AC / 50-60Hz, lin=0.12A, power factor > 0.95, inrush current < 0.2A
output	24V ± 0.5V PWM
max. output current I <sub>led</sub>	1A
galvanic isolation	SELV
control input	DALI or SwitchDim2
number of DALI-addresses	2mA
number of DALI addresses	operating mode DT8, Dim2Warm: 1 operating mode Balance&Dim: 2

limensions (L x W x H)	120mm x 41mm x 22mm
nounting/housing	remote ceiling / integration in luminaires
expected lifetime (at tc<=65°C)	>50000h
nousing material	PC, class V0
protection degree housing	IP40
rotection degree terminals	IP20
oower on behaviour	configurable via DALI: 0%-100% or last value

#### environmental conditions


storing and transportation	-20°C +75°C
temperature	-20 C +73 C
operational ambient	-20°C +45°C
temperature	-20 C +45 C

#### terminals

spring terminal connector (push in cage clamp)
0,2 1,5mm² (AWG 24 AWG 16)
0,2 1,5mm² (AWG 24 AWG 16)
0,25 1mm²
8,5 9,5mm / 0,33 0,37 inch
PA66, class V0
push button




IEC 61347-2-13 IEC 61000-3-2 CISPR 15 IEC 61547 IEC 62384




#### **Typical Application – Constant Voltage**

DALI:



SwitchDim2:




#### constant current (CC)

type	DALI LED Power Supply CW-WW CC						
article number	89453849- CWW-350	89453849- CWW-500	89453849- CWW-700	89453849- CWW-800	89453849- CWW-1050		
electrical data							
supply voltage			V AC / 50-60Hz, or > 0.95, inrush				
max. output current I <sub>led</sub>	350mA	500mA	700mA	800mA	1050mA		
output voltage range V <sub>led</sub>	12V-44V	12V-36V	12V-26V	12V-26V	12V-17V		
galvanic isolation			SELV				
control input			DALI				
current consumption DALI			2mA				
number of DALI-addresses		-	ng mode DT8, Di ing mode Balan				
general data		operat	ing mode balan				
dimensions (L x W x H)		12	0mm x 41mm x	22mm			
mounting/housing		remote cei	ling / integratio	n in luminaires			
expected lifetime (at tc<=65°C)			>50000h				
housing material			PC, class VO				
protection degree housing			IP40				
protection degree terminals			IP20				
power on behaviour		configurable	via DALI: 0%-10	0% or last value			
environmental conditions							
storage/transportation temp.			-20°C +75°0	C			
ambient temperature			-20°C +45°(	C			
terminals							
connection type		spring termin	al connector (pu	sh in cage clamp)			
wire size solid core	0,2 1,5mm² (AWG 24 AWG 16)						
wire size fine wired	0,2 1,5mm <sup>2</sup> (AWG 24 AWG 16)						
wire size using wire end ferrule	0,25 1mm <sup>2</sup>						
stripping length		8,5	9,5mm / 0,33	0,37 inch			
housing material			PA66, class V	0			
actuation type		push button					

on request: output currents from 250mA to 1050mA available




IEC 61347-2-13 IEC 61000-3-2 CISPR 15 IEC 61547 IEC 62384




#### **Typical Application – Constant Current**

DALI:



SwitchDim2:



### Installation

- The DALI LED PS is an independent control gear, it is suitable for remote ceiling and integration in luminaires
- Ensure proper working cable relief for installation in protection class II equipment
- The wiring should be carried out as a permanent installation in a dry and clean environment.
- Installation may only be carried out in a voltage-free state of the system and by qualified specialists.
- National regulations for setting up electrical systems must be followed.
- Connect power supply terminals L and N to mains voltage according to the labelling.
- the connection to the DALI-line (DA,DA) is polarity free
- If used in Sw&Dim2 mode for both inputs the same phase has to be used
- Wiring topology of the DALI-line: line, tree, star
- Connect only one wire on each terminal, if twin ferrules are used, take note of the maximum wire size
- The DALI wiring can be realised with standard low-voltage installation material. No special cables are required.
- The DALI line may be routed together with the mains voltage (in one cable or as single wires in a tube)



## Attention: Do not connect or disconnect the LED when voltage is applied



Attention: The DALI-signal is not classified as SELV circuit (Safety Extra Low Voltage). Therefore, the installation regulations for low voltage apply



The voltage drop on the DALI line must not exceed 2V at maximum length (300m) and maximum bus load (250mA).

### Commissioning

- After connection the LED PS is ready to use. Delivery default settings see page
   Error! Bookmark not defined..
- The device can be addressed with the DALI Cockpit PC Software.
   When using the DALI Cockpit Software, the PC must be connected to the DALI bus via a suitable interface module (DALI-2 USB; DALI USB, DALI-2 WLAN, DALI-2 Display, DALI-2 IOT, DALI 4Net, DALI SCI RS232). The LED PS is automatically recognised by the DALI Cockpit during the addressing process and listed in the device overview.
- Scene values, groups, DALI parameters and device specific settings can be configured in the DALI Cockpit, see section DALI Cockpit: General Settings page 9 and following.

### **Operating Modes**

The device offers several operating modes:

### DT8 (factory default)

Default when connected to DALI in this operating mode one DALI-address for the independent control of light level and colour temperature is used (Device Type 8 Mode Tc).

**SwitchDim2**: Alternatively, the device can be controlled using 2 switch-inputs for mains voltage (SwitchDim2):

SW&DIM2-1: light level short press: On/Off long press: dimming SW&DIM2-2: colour temperature long press: change colour temperature


#### Balance&Dim

This operating mode is also suitable for operating tuneable white luminaires using two DALI-addresses. The first controls the light level and the second is used for changing the distribution on the output channels (e.g. for tuneable white applications or balancing direct/indirect lighting).

The Balance&Dim mode allows colour temperature adjustments without affecting the light level and vice versa. For each channel only, DALI-standard commands like dim up/down but also DAP are used. Thus, the device can be used with all common controls and gateways (e.g. KNX). The Balance&Dim mode provides an alternative to the DT8-Tc mode.

#### Can be operated via DALI or SwitchDim2:

DALI-address 1, SW&DIM2-1: light level DALI-address 2, SW&DIM2-2: balance





#### Dim2Warm

Both output channels are controlled by one DALI-address or SwitchDim2-input. The balance is coupled directly to the DALI dim level – the smaller the dim level the warmer the light.

<u>DALI-address / SW&DIM2-1</u>: Dim2Warm (Master)

short press: On/Off long press: dimming





The dim2warm table can be edited in the DALI Cockpit Software, see section DALI Cockpit: General Settings page 9 (Overview operating mode Dim2Warm).

### Selection of operating mode

With the help of the PC-software tool DALI-Cockpit the operating mode can be easily set on the general settings page.

	DALI CW-WW LED Power Supply (A0)
	DALI CW-WW LED Power Supply
Operating	Mode
DT8 - Tc	Change
	Operation Mode set X
	Operation Modes
	DT8 - Tc
	⊖ Balance&Dim
	○ Dim2Warm
	Set Cancel

Switching between operating modes can also be done with the help of the DALI-command SET OPERATING MODE (IEC 62386-102 Ed.2). When changing the operating mode, the number of used DALI-addresses can change as well, and this requires a new addressing procedure. In the DALI-Cockpit this address assignment is performed automatically.

Operating Mode:

Number	Operating Mode
0x0	DT8 (factory default)
0x92	DT8
0x94	Balance&Dim
0x95	Dim2Warm

### DALI Cockpit: General Settings

On the overview page respective control elements are available for each operating mode

- *DT8:* 2 sliders, one for level and one for colour temperature
- *Balance&Dim:* 2 sliders, one for level and one for balance
- Dim2Warm: 1 slider for input value adaption and an Edit-Function for the Dim2Warm-table.

Additionally, the following configurations can be made:

#### **PWM Frequency**

The PWM frequency can be selected: 122Hz / 244Hz / 488Hz / 976Hz. From FW version 5 changed PWM frequencies: 122Hz / 250Hz / 500Hz / 1kHz.

#### Ignore Broadcast Commands

The broadcast control of each channel can be deactivated individually. Through selection of "Ignore Broadcast", the respective channel does no longer respond to broadcast commands on the DALI bus (group assignments are not ignored).

#### Adjustable RESET behaviour

From FW 5. on the response to a DALI reset command is configurable. The following options are available:

- Ignore command: the DALI reset command does not trigger any changes to the device settings.
- DALI standard: the selected device settings are reset to the values defined in the DALI standard (see table 1 below second column: DALI standard values)
- Custom settings: the current device settings can be saved. With a DALI Reset command, the selected parameters (6 check boxes) are then reset to these saved values.

#### **Calibration - light adjustment**


The dimming range reaches from 0.1% to 100%. From FW version 5 on, it is possible to calibrate different light sources, with the option: "LED Calibration".

For each channel, the MIN level (default: 0.1%) an intermediate value (default: 33%)

and the MAX level (default: 100%) can be adjusted and matched between light sources.

To do this, the desired level with the upper slider needs to be set. Apply the value and start the fine adjustment by pressing the button next to it. The appropriate fine adjustments can now be made with the calibration slider below. See also Figure 1

#### Overview operating mode DT8



Overview operating mode Balance&Dim

Device Parameters

Operating Mode		PWM Frequency	
Balance&Dim	<b>i</b> )	max. efficiency (~250Hz)	~
Change		LED Calibration <i>i</i>	
Ignore Broadcast Config and Arc commands	<i>i</i> )	Behavior on DALI Reset Command	
Control Gear 1	•	Parameters are reset to DALI Standard vallues.	Change
Control Gear 2		Standard values.	
Intensity Control (A5)			
		0 %	Set
Balance Control (A6)			
Channel 1		Channel 2	
50.00 %		50.00 %	Set

Operating Mo	de			PWW	I Frequency	y		
Dim2Warm			<i>i</i> )	ma	x. efficienc	y (~250Hz)		~
		Ch	ange		LED Calibr	ration	<b>i</b>	
Ignore Broado	ast Config	and Arc com	mands i	Beha	avior on DA	LI Reset Co	mmand	
Ignore Bro	adcast con	nmands	٢	Para	meters are dard vallue	reset to DA	ALI	Change
Dimm2Warm Ta	belle							
Edit		Set Default						
N.	_							
100								
90 80 70 60								
60 50 40		1	-					
20								
		0 0 0	100					
Dim2Warm Co	ontrol (A5)	10 <u>2</u> 5 50	100 %					
29 10 0.1 0.3	, 28 k	12 23 50	100 T.				0 %	Set
Dim2Warm Co		10 25 50	- 700					Set
Dim2Warm Co	t Dim2War	10 15 50	s				0 % ×	Set
Dim2Warm Co	t Dim2War n To Warm '	Table	-		Colds			Set
Dim2Warm Co	t Dim2War n To Warm <sup>•</sup> Master %	Table CW %	WW %	^	Cold:	Warm:	×	Set
Dim2Warm Co	t Dim2War n To Warm '	Table	WW %		Cold:		×	Set
Dim2Warm Co	t Dim2War n To Warm Master % ),1	CW %	WW %				×	Set
Edi	t Dim2War n To Warm <sup>-</sup> Master % 0.1 0.155	CW % 0.05 0.05	WW % 0.50 1.00				×	Set
Dim2Warm Co	t Dim2War n To Warm <sup>•</sup> Master % .1 .155 .246	Table CW % 0.05 0.05 0.05	WW % 0.50 1.00 2.50				×	Set
Dim2Warm Co	t Dim2Warm <sup>*</sup> m To Warm <sup>*</sup> Master % ).155 ).155 ).246 ).392	Table CW % 0.05 0.05 0.05 0.05	WW % 0.50 1.00 2.50 4.50				×	Set
Edi	t Dim2Warm 'n Master % 0.1 0.155 0.246 0.392 0.623	Table CW % 0.05 0.05 0.05 0.05 0.05 0.05	WW % 0.50 1.00 2.50 4.50 7.50				×	Set
Edi	t Dim2Warm 'n Master % ).1 ).155 ).246 ).392 ).623 ).991	CW % 0.05 0.05 0.05 0.05 0.05 0.05 0.05 0.0	WW % 0.50 1.00 2.50 4.50 7.50 10.50				×	Set
Edi	t Dim2War 1 n To Warm 1 Master % ).1 ).155 ).246 ).392 ).623 ).991 1.576	Table CW % 0.05 0.05 0.05 0.05 0.05 0.10 0.25	WW % 0.50 1.00 2.50 4.50 7.50 10.50 14.00				×	Set
Edit	t Dim2War 1 n To Warm 1 Master % ).1 ).155 ).246 ).392 ).623 ).991 1.576 2.51	Table CW % 0.05 0.05 0.05 0.05 0.05 0.10 0.25 0.50	WW % 0.50 1.00 2.50 4.50 7.50 10.50 14.00 17.50				×	Set
Edd	t Dim2War n To Warm 'n Master % ).1 ).155 ).246 ).392 ).623 ).991 1.576 2.51 3.88	CW % 0.05 0.05 0.05 0.05 0.05 0.10 0.25 0.50 1.00	WW % 0.50 1.00 2.50 4.50 7.50 10.50 14.00 17.50 21.00				×	Set

\*Change of the Dim2Warm table are being saved via "Save" to the device as other device parameters

Overview operating mode Dim2Warm

Douico Daramotoro




Figure 1 Cockpit overview page – LED calibration and settable RESET behaviour

### DALI Cockpit: Additional Settings

Besides the settings on the general page each channel can be selected separately in the component tree for individual configuration.

DALI CW-WW LED Power Supply (A0)
 DALI CW-WW LED Power Supply (A0)

For each address the group membership can be set as well as scene values and DALIparameters. In Balance&Dim operating mode all values assigned to channel 2 are representing the balance.

*Figure 2* on page 13 shows the setting options for operating mode DT8.

Figure 3 on page 13 shows the settings for each channel for operating modes Balance&Dim and Dim2Warm.

## DT8 – Tc Limits and Colour Temperature step size

The Tc step size can be increased (instead of the DT8 Tc DALI standard value: 1), to speed up colour temperature changes when using the commands TC STEP COOLER/WARMER.

Tc StepSize 5

The values "Physical Warmest"/"LED Warmest" ad "Physical coolest"/"LED coolest" capture the range the connected LED allows.

"Tc warmest" and "Tc coolest" colour temperatures represent the limit values for colour temperature like the Min and Max level do for the brightness. These values can be

adjusted to compensate for colour differences between different light sources.

mits	
Physical Warmest	
Physical Coolest	
Tc Warmest	
Tc Coolest	

#### Scene settings


Via the arrow button the scene settings can be imported and exported.

Preferences	-
Import from file Export to file	
All Scenes	>

Via the button "Preferences" the default scene settings can be loaded.

F	Preferences							
Scene	Scene preset selection X							
Scen	Scene set:							
Defa	ault				$\sim$			
0	MASK %	6535K	8	MASK %	4016K			
1	MASK %	6060K	9	MASK %	3831K			
2	MASK %	5649K	10	MASK %	3663K			
3	MASK %	5291K	11	MASK %	3508K			
4	MASK %	4975K	12	MASK %	3367K			
5	MASK %	4694K	13	MASK %	3236K			
6	MASK %	4444K	14	MASK %	3115K			
7	MASK %	4219K	15	MASK %	3003K			
	OK Cancel							

From FW 6 on, extended scene settings can be configured. With extended scenes it is possible to automatically change between 2 scene values (once or looped). Thereby enabling configuration of blinking lights, time delayed switch off or light repetitions, as well as traveling lights with multiple dimmers.



Extended Scenes are available for each of the 16 scenes on the second tab:

Device Parameters Extended Scenes


loop

By enabling the extended scenes these are used instead of the standard scenes on the "Device Parameters" tab

extended scene functionality 🥡

#### Import/Export settings

With a right click on the channel in the devicetree overview the device settings can be exported or imported.



evice Parameters					
Groups					
0 1 2 3 4 5 6	7 8	9 1	0 11	12 13	14 15
DALI Parameter					
MIN Level:					0.1 %
MAX Level:					100 %
Power On Level:					100 %
Power On Colour 🥥 Tc: MASK K					
System Fail Level:					100 %
System Fail Color 🥥 Tc: MASK K					
Fade time 🔿				e	t fade s
Ext Fade Time 🖲					fastest
Fade rate					11.2 step/s
Scenes					1
				Preferen	nces 🔻
0 🔽 🌔 MASK % Tc: 65	85 K 8	3 🗸 🕥 🗌	MASK %	Tc:	4016 K
1 🔽 🥥 MASK % Tc: 60	50 K 9	• 🗹 🔾 🗌	MASK %	Tc:	3831 K
2 🗸 💭 MASK % Tc: 56	49 K 1	0 🗹 🥥 🗌	MASK %	Tc:	3663 K
3 🗹 💭 MASK % Tc: 52	91 K 1	1 🗸 🔾 🗌	MASK %	Tc:	3508 K
4 🗸 💭 MASK % Tc: 49	75 K 1	2 🗸 🔾	MASK %	Tc:	3367 K
5 🔽 🌔 MASK % Tc: 46	94 K 1	3 🗸 🔾	MASK %	Tc:	3236 K
6 🔽 🌔 MASK % Tc: 44	44 K 1	4 🗹 🔘	MASK %	Tc:	3115 K
7 🗸 💭 MASK % Tc: 42	19 K 1	5 🗸 🔾	MASK %	Tc:	3003 K
Tc Limits Physical Warmest					1501 K
Physical Coolest				- <b>1</b> 4	7518 K
Tc Warmest					1501 K
Tc Coolest					7518 K

Figure 2 Cockpit settings for DT8

evice Parameters			
Groups			
0 1 2 3	4 5 6 7	8 9 10 11	12 13 14 15
DALI Parameter			
MIN Level:			0.1 %
MAX Level:			100 %
Power On Level:			100 %
System Fail Level:			100 %
Fade time 🔿			ext fade 5
Ext Fade Time 🖲			fastest
Fade rate			44.7 step/
Scenes			
			Preferences
0 🗹 🔆 100 %	4 🗹 🔆 🚺 100 %	8 🗹 🔆 🛛 100 %	12 🗹 🔆 🚺 100 %
1 🗹 🔆 🛛 %	5 🗹 🔆 🛛 %	9 🗹 🔅 🛛 %	13 🗹 🔆 🛛 0 %
2 🗹 🔆 🛛 100 %	6 🗹 🔆 🛛 100 %	10 🗹 🔆 100 %	14 🗹 🔆 🛛 100 %
	7 🗹 🔆 🛛 %	11 🗹 🔆 🛛 %	15 🗹 🔆 🛛 %

Figure 3 Cockpit settings for each channel - Balance&Dim and Dim2Warm

### Factory Default Settings

Before the initial addressing is performed, the device can already be controlled by a group address. This predefined grouping will be deleted during the first addressing procedure. Afterwards groups can be assigned as usual (e.g. with the help of the DALI Cockpit). By sending a DALI-Reset command the device is set to DALI default values as defined in the standard.

The factory default values as well as the DALInorm values are summarised in *Table 1* below.

	Delivery default			DALI norm	
Operating mode	DT8		N/A (remains unchanged		
SwitchDim2	SW&DIM2-2	L: light level		N/A (remains unchanged	
	SW&DIM2-2	2: colour tempe			
Min Level	0.1%			0.1%	
Max Level	100%			100%	
Power On Level	Last light lev	/el (= MASK)	100%		
System Failure Level	100%			100%	
Fade Time	1s [2]			none	
Fade Rate	89.4 steps/s	5 [5]	44.7 steps/s		
Tc-step size	3		N/A (remains unchanged		
PWM-Frequency	CV: 1kHz			N/A (remains unchanged	
	CC: 250Hz				
Control before initial	G0		None		
addressing	(G0 and G1	in operating m			
Scene values	Scene	light level	colour temperature	All scene values MASK	
	0	MASK	6535 K		
	1	MASK	6060 K		
	2	MASK	5649 K		
	3	MASK	5291 K		
	4	MASK	4975 K		
	5	MASK	4694 K		
	6	MASK	4444 K		
	7	MASK	4219 K		
	8	MASK	4016 K		
	9	MASK	3831 K		
	10	MASK	3663 K		
	11	MASK	3508 K		
	12	MASK	3367 K		
	13	MASK	3236 K		
	14	MASK	3115 K		
	15	MASK	3003 K		
Behaviour on DALI RESET command	set DALI Sta	ndard values, s	ee column 2	N/A (remains unchanged	

### Table 1 factory default settings column 1, DALI Standard settings column 2

Purchase Order Information

Art. Nr. 89453849-CWW-24V: DALI 25W CW-WW LED Power Supply, constant voltage (CV), 24V, 25W, Imax=1A, SwitchDim2, remote ceiling

Art. Nr. 89453849-CWW-350: DALI CW-WW LED Power Supply, constant current (CC) 350mA, Uout=12V-44V, SwitchDim2, remote ceiling

Art. Nr. 89453849-CWW-500: DALI CW-WW LED Power Supply, constant current (CC) 500mA, Uout=12V-36V, SwitchDim2, remote ceiling

Art. Nr. 89453849-CWW-700: DALI CW-WW LED Power Supply, constant current (CC) 700mA, Uout=12V-26V, SwitchDim2, remote ceiling

Art. Nr. 89453849-CWW-800: DALI CW-WW LED Power Supply, constant current (CC) 800mA, Uout=12V-26V, SwitchDim2, remote ceiling

Art. Nr. 89453849-CWW-1000: DALI CW-WW LED Power Supply, constant current (CC) 1000mA, Uout=12V-17V, SwitchDim2, remote ceiling

Art. Nr. 89453849-CWW-1050: DALI CW-WW LED Power Supply, constant current (CC) 1050mA, Uout=12V-17V, SwitchDim2, remote ceiling

### Additional Information and Equipment

DALI-Cockpit – DALI system configuration tool, free when using a Lunatone interface device <u>https://www.lunatone.com/en/product/dali-</u> <u>cockpit/</u>

Lunatone DALI products http://www.lunatone.at/en/

Lunatone datasheets and manuals <a href="http://lunatone.at/en/downloads/">http://lunatone.at/en/downloads/</a>

### Contact

Technical Support: <a href="mailto:support@lunatone.com">support@lunatone.com</a>

Requests: sales@lunatone.com

www.lunatone.com



#### Disclaimer

Subject to change. Information provided without guarantee. The datasheet refers to the current delivery.

The compatibility with other devices must be tested in advance to the installation.